

**TF385: TF OLD FLAT TOP STYLE SAFARI RAISED AIR INTAKE SOCK****FITTING INSTRUCTIONS**

1. Put the car into gear or park and apply the hand brake.
2. The Terrafirma Safari snorkel sock simply slips over the grill on the front of the air intake head to help filter out dust particles.

