



## **TF574: TERRAFIRMA EXTREME REAR LOWER BODY CORNERS**

### **DEFENDER 90**

### **FITTING INSTRUCTIONS**

1. Put the car into gear or park and apply the hand brake.
2. Identify the correct Terrafirma extreme lower body corner for the side you are working on.
3. Remove the rear lower lamp, usually indicator. Remove the rear lower reflector if fitted below the lamp.
4. Offer up the Terrafirma extreme lower body corner to the car using the mounting points and holes for the lamp to guide you on correct location.
5. Make sure the large round cut outs in both the extreme body corner and the car are the same and the small mounting hole for the fixing screw and correct. These are your starting point datum so need to be right.
6. Measure the distance from the smaller hole to the top of the extreme body corner and then mark this on the car, this will give you the top line. Double check this is correct.
7. With something that wont damage the paintwork, draw a line along the rear wing from the point you have marked towards the wheel arch. Make sure this is straight, this will be the top line of the extreme body corner, do not cut along this line! Double check this is correct.
8. Measure down from the top edge of the extreme body corner to the first inwards fold, transfer this measurement on to you wing and measure down from the initial top line, draw a second line, this lower second line will be the cut line so double check, make sure you are happy and then check again.
9. Undo at least the rear half of the clips and bolts that hold the rear wheel arch / eyebrow to the wing and free it from the rear most part of the wing.
10. Double check all your measurements an that the lines are correct and straight then cut along the lower line to the rear body capping.
11. The rear body capping and the rear most panel will also need to be trimmed. Don't cut too much in one go, keep offering the extreme body corner up so you get the correct fit.
12. With the extreme body corner now in place, re-fit the rear lamp and rear reflector.
13. Make sure the extreme body corner is in the correct position, mark and drill the mounting holes, these are then best secured with rivets. When the extreme body corner is securely fitted the rear wheel arch / eyebrow needs to be put back into place, it will then need to be marked and trimmed to follow the desired line that you want. Double check all your lines before you cut.
14. Repeat the procedure for the second side.

**WARRANTY & DISCLAIMER** - Terrafirma products are warranted free from defects in materials and workmanship for a period of 12 months from the date of retail invoice. Terrafirma does not warrant that the products manufactured or marketed by it comply with the laws of the country where those goods are purchased or used. It is the sole responsibility of the purchaser to ascertain whether products being purchased, or the fitting of those products to any other object, comply with local laws. This warranty covers structural defect and workmanship but does not cover finishes, labour charges for removal or refitting, freight costs, accident damage, misuse or abuse, damage due to incorrect or improper fitment or application, modified product, faulty design or consequential damage of any kind. Damage or defects caused by collision, alteration, improper installation, road hazards, adverse conditions or usage for any other purpose other than normal private usage are not covered by this warranty. Terrafirma shall not be liable for any other claim relating to the use of the product and any indirect special or consequential damage or injury to any person, company or other entity. All claims must be accompanied by the original retail invoice and should be submitted to the supplying Allmakes 4x4/Terrafirma distributor. This warranty covers only the replacement of the product or part concerned. The decision remains solely at the discretion of Allmakes Ltd. The information contained in this catalogue was correct at the time of going to press. Allmakes/Terrafirma and its associated companies reserve the right to alter the range and any product specifications without notice. Always consult your Allmakes/Terrafirma distributor for the latest product information and specifications. The Terrafirma range of products is constantly being evaluated for enhancement and improvement to make sure the level of quality and performance is as expected.